


WINNERS ONLY[®] Assembly Instructions


ABF148SE 48" SOFA TABLE

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

COMPONENT LIST:

PART NO	FIGURE	DESCRIPTION	QTY
ABF148SE-01		Hardware Bag	1 pce
ABF148SE-13		Table Top	1 pce
ABF148SE-07		Legs	4 pcs
ABF148SE-25		Apron A	1 pce
ABF148SE-26		Apron B	1 pce
ABF148SE-22		Fixed Shelf	1 pce

HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1		Hex Nut	4 pcs
2		Lock Washer (Large)	4 pcs
3		Flat Washer (Large)	4 pcs
4		Box-End Wrench	1 pce
5		JCBC Bolt	8 pcs
6		Lock Washer (Small)	8 pcs
7		Flat Washer (Small)	8 pcs
8		Allen Key	1 pce
9		Pan Head Screw	4 pcs


This product will take 15-20 minutes to assemble.

Reminders

1. Use only the hardware supplied.
2. Once the product is assembled, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening.

NOTE:

1. Two or more people are needed for assembly.
2. Please keep all hardware parts out of the reach of children.



WINNERS ONLY


Assembly Instructions

ABF148SE 48" SOFA TABLE

ASSEMBLY :


STEP 1

- 1.1-Turn the **Table Top** upside down on a protective surface such as carpet or other soft material.
- 1.2-Attach the **Apron A** into the **Table Top** and secure using **Flat Washer(Small)**, **Lock Washer(Small)** and **JCBC Bolt** and **Allen Key** provided as shown in the diagram.




STEP 2

- 2.1-Align **Apron B** to **Apron A** forming an "X", and secure using **Flat Washer(Small)**, **Lock Washer(Small)**, **JCBC Bolt** and **Allen Key** provided as shown in the diagram.




STEP 3

- 3.1-Insert three Legs into the **Apron** and secure with **Flat Washer(Large)**, **Lock Washer(Large)** and **Hex Nut** using **Box-End Wrench**. Do not fully tighten yet.
- 3.2-Insert the **Fixed Shelf** into the leg assembly, then insert the fourth leg into the **Apron** and secure with using **Flat Washer (Large)**, **Lock Washer(Large)** and **Hex Nut** using **Box-End Wrench**. Do not fully tighten yet.
- 3.3-Insert the **Pan Head Screw** into pre-drilled holes on the corner block of **Fixed Shelf** and tighten using a **Screw driver(Not provided)**.



STEP 4

- 4.1- Turn table to upright position.
- 4.2- Apply pressure on all four corners of the table to make sure it is properly balanced. Fully tighten all four **Hex Nuts**.



CARE INSTRUCTION

- ~ Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.