


WINNERS ONLY®

Assembly Instructions


DBCT155024NE / DBCT155024P

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

COMPONENT LIST:

PART NO	FIGURE	DESCRIPTION	QTY
DBCT155024NE-01		Hardware Bag	1 pce
DBCT155024P-01			
DBCT155024NE-02		Chair Back	1 pce
DBCT155024P-02			
DBCT155024NE-03		Wood Seat	1 pce
DBCT155024P-03			
DBCT155024NE-06		Front Leg (Left)	1 pce
DBCT155024P-06			
DBCT155024NE-05		Front Leg (Right)	1 pce
DBCT155024P-05			
DBCT155024NE-10		Front Stretcher	1 pce
DBCT155024P-10			
DBCT155024NE-07		Side Stretcher (L/R)	2 pcs
DBCT155024P-07			

HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1		Pan Head Screw	6 pcs
2		JCBC Bolt(Short)	2 pcs
3		JCBC Bolt(Long)	8 pcs
4		Lock Washer	10 pcs
5		Flat Washer	10 pcs
6		Allen Key	1 pce
7		Glue	1 pce


Reminders

1. Use only the hardware supplied.
2. Once the product is assembled, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening.

NOTE:

1. Two or more people are needed for assembly
2. Please keep all hardware parts out of the reach of children.

This product will take 15-20 minutes to assemble.



WINNERS ONLY ®

Assembly Instructions


DBCT155024NE / DBCT155024P

ASSEMBLY :

STEP 1


Step1: Attached wood seat to the chair back using the provided hardware as shown on Fig.1.1 and Fig.1.2.

Step2: Attached front legs (Left and Right) to wood seat and the side and front stretchers to front legs and chair back using the provided hardware as shown in Fig.2.1 and Fig.2.2



STEP 2


IMPORTANT: Please make sure to position the front stretcher lower than the side stretchers.



STEP 3

3.1- Turn the chair to standing position.

3.2- Check it's balance and tighten all screw and bolts to complete the assembly.



Assembly is now Completed.

CARE INSTRUCTION

- ~ Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.